


### MEASURE THE WIDTH OF YOUR WINDOW:

Measure the visible glass area of each window or door from the inside edges of the frame where the glass meets the rubber bead.

- A. Measure the top, middle and bottom of the glass to the nearest mm and note down the shortest measurement.
- B. Only measure up to the edge of the rubber bead, don't include it in your measurement.




01

### MEASURE THE LENGTH OF YOUR WINDOW:

Measure the visible glass area of each window or door from the inside edges of the frame where the glass meets the rubber bead.

- A. Measure the top, middle and bottom of the glass to the nearest mm and note down the shortest measurement.
- B. Only measure up to the edge of the rubber bead, don't include it in your measurement.



02